


SHOWER WALLNUT™



/// Removal Tool

BRAND BY
Sioux Chief



Installation Instructions

1. Remove showerhead then shower arm.
2. Remove escutcheon from Shower WallNut.
3. Turn hex head machine screw counter clockwise to pull machined end into removal tool pipe nipple so nipple can screw into WallNut.
4. Thread nipple into WallNut (hand-tight).
5. Turn hex screw clockwise to engage copper tube.
6. Using 7/16" wrench continue turning screw until WallNut has been disengaged from stub out.
7. Discard used WallNut and replace.